

StorMaster COMBO

STORMASTER COMBO INSTALLATION GUIDELINES

1. Remove StorMaster Combo from packing and inventory all parts.

2. Start by assembling the header bar and mount brackets. Attach brackets using supplied bolt, washers and nuts, leave loose.

A) If the bed has removable tie downs in the front of the bed, remove them and keep the factory bolts, these will be used for mounting the bracket/header bar assembly.



B) If the bed has a D-Rings in the front you will use the supplied bolt/washer/nut, mount plate and spacers to sandwich the D-Ring between the mount plate and the bracket.

3. Install front Bracket/Header Assembly to Tie Downs.
4. Insert StorMaster System into the bed. Note – The Bed System can be installed as one with Drawer System or Track only; whichever is easier for the installer.



*****To Remove Bed System**, turn handle to open position and slide deck all the way out. Once at the end of the track, lift the deck to a 45' angle and lift out and over welded stop points. ***

Once the drawer system is in the bed, push the drawer forward and align the studs on the front of the drawer bracket to the main bar.

5. With the Drawer installed, align the Bed System and tighten all bolts. Test the Bed System to ensure unit glides in and out. Lithium grease or similar lubricant can be used in the Track system to help with functionality.

